

## REQUEST FOR QUOTATION LOCAL PURCHASE SECTION

**RFQ NUMBER** : 2332600283  
**DATE** : 30.01.2026  
**REQ No** : 1032600491  
**REQ TITLE** : Plugging 1032600491  
**DELIVERY LOCATION**  
**CLOSING DATE** : 05.02.2026  
**CLOSING TIME** : 10:00:00

SL NO	ITEM CODE	SERVICE ID	DESCRIPTION	QTY	UOM	BRAND/ORIGIN	WARRANTY	UNIT PRICE	TOTAL PRICE
1		ITEM-00001	<p>DETAILED SPEC - PLUGGING / BACK FILLING EXISTING CANCELLED WELLS AT DIFFERENT WELL FIELD AND SHABIAS (AL AWEER, WAHOOSH, HABAB, MARGH AM WELLFIELD AREA &amp; KHAWANEEJ, MURRAH, MARGHAM ETC..) WITH BENTONITE PELLETS OR SUITABLE METHOD. TOTAL # 50 NUMBER WELL-PLUGGING STEP SMAKING SURE THAT THE PROPER EQUIPMENT AND MATERIALS ARE ON HAND WILL MAKE THE JOB MUCH EASIER, QUICKER AND EFFECTIVE. WELL DETAILS. WE LL ID # LIST ATTACHED WELL DIA : 8# # 14# WELL DEPTH: 202 - 300FT SWL#- 130 - 180 FITCASING HEIGHT FROM EGL : 1 - 2FT STEP 1. MEASURE THE DIMENSIONS OF THE WELL. MEASUREMENTS MUST BE TAKEN OF THE WELL DIAMETER, DEPTH AND WATER LEVEL. ACCURATE MEASUREMENTS (NOT ESTIMA TES) WILL ALLOW THE CORRECT CALCULATION OF THE TOTAL WELL VOLUME AND THE VOLUME OF WATER IN THE WELL. THIS INFORMATION IS NEEDED TO DE</p>	50	EA				

## REQUEST FOR QUOTATION LOCAL PURCHASE SECTION

**RFQ NUMBER** : 2332600283  
**DATE** : 30.01.2026  
**REQ No** : 1032600491  
**REQ TITLE** : Plugging 1032600491  
**DELIVERY LOCATION**  
**CLOSING DATE** : 05.02.2026  
**CLOSING TIME** : 10:00:00

SL NO	ITEM CODE	SERVICE ID	DESCRIPTION	QTY	UOM	BRAND/ORIGIN	WARRANTY	UNIT PRICE	TOTAL PRICE
			<p>TERMINE THE AMOUNT OF MATERIALS NEEDED FORPLUGGING. REMEMBER THAT VOLUME CALCULATIONS DEPEND ON THE SHAPE OF THEWELL. OUR WELLS ARE CYLINDRICAL; HOWEVER, SOME HAVE OTHER SHAPES THATMUST BE CONSIDERED FOR ACCURATE CALCULATION OF VOLUME.STEP 2. REMOVE ALL OBSTRUCTIN G MATERIALS FROM THE WELL.MAKING SURE THAT FILL MATERIALS DO NOT SLUMP OR SETTLE IS CRITICAL;THEREFORE, OBSTRUCTIONS THAT MAY CAUSE INCOMPLETE FILLING OF THE VOIDSMUST BE REMOVED. REMOVE THE PUMP, RODS, PIPES AND ANY OTHER EQUIPMENTFROM THE WELL. FLOATING DEBRIS, SUCH AS WOOD STAVES, ALSO SHOULD BEREMOVED. ONE METHOD USED TO ACCOMPLISH DEBRIS REMOVAL IS FLUSHING. IFWATER IS PUMPED INTO THEWELL , FLOATING DEBRIS WILL MOVE TO THE TOP AS THE WELL FILLS WITH WATER.FLUSHING MAY NOT BE POSSIBLE WITH LARGER DIAMETER WELLS DUE</p>						

## REQUEST FOR QUOTATION LOCAL PURCHASE SECTION

**RFQ NUMBER** : 2332600283  
**DATE** : 30.01.2026  
**REQ No** : 1032600491  
**REQ TITLE** : Plugging 1032600491  
**DELIVERY LOCATION**  
**CLOSING DATE** : 05.02.2026  
**CLOSING TIME** : 10:00:00

SL NO	ITEM CODE	SERVICE ID	DESCRIPTION	QTY	UOM	BRAND/ORIGIN	WARRANTY	UNIT PRICE	TOTAL PRICE
			TO THE VOLUME OF WATER REQUIRED. IN ANY EVENT, AS MUCH DEBRIS AS POSSIBLE MUST BE REMOVED FROM THE WELL BEFORE PLUGGING. INITIAL WELL-PLUGGING STEPS INCLUDE ACCURATE MEASUREMENT OF THE WELL DIMENSIONS AND REMOVAL OF ALL OBSTRUCTIONS. STEP 3. DISINFECT THE WELL BY ADDING HOUSEHOLD BLEACH. ALL WELLS CONTAINING STANDING WATER MUST BE DISINFECTED TO KILL EXISTING MICROORGANISMS. THIS CAN BE ACCOMPLISHED BY ADDING CHLORINE BLEACH AT THE RATE OF 1 GALLON OF BLEACH FOR EVERY 500 GALLONS OF WATER AND IS EQUIVALENT TO A #SHOCK# CHLORINATION CONCENTRATION OF 100 PARTS PER MILLION OF CHLORINE. THE CHLORINATION PROCESS ENSURES THAT DISEASE-CAUSING MICROORGANISMS ARE NOT SEALED IN THE AQUIFER. THE CHLORINATION PROCEDURE DISINFECTS THE WELL SO THAT						

## REQUEST FOR QUOTATION LOCAL PURCHASE SECTION

**RFQ NUMBER** : 2332600283  
**DATE** : 30.01.2026  
**REQ No** : 1032600491  
**REQ TITLE** : Plugging 1032600491  
**DELIVERY LOCATION**  
**CLOSING DATE** : 05.02.2026  
**CLOSING TIME** : 10:00:00

SL NO	ITEM CODE	SERVICE ID	DESCRIPTION	QTY	UOM	BRAND/ORIGIN	WARRANTY	UNIT PRICE	TOTAL PRICE
			<p>DISEASE-CAUSING MICROORGANISMS ARE NOT SEALED IN THE AQUIFER AFTER THE WELL IS PLUGGED. STEP 4. FILL THE WELL WITH PLUGGING MATERIALS. PLUGGING ALWAYS BEGINS AT THE WELL'S BOTTOM. THE KIND OF AQUIFER, WELL STRUCTURE, DEPTH, DIAMETER, MATERIAL AVAILABILITY, AND NECESSARY LEVEL OF PROTECTION WILL ALL AFFECT THE PRECISE PLUGGING PROCESS. THE WELL CAN BE SEALED WITH BENTONITE, 3/8 GRAVEL, BENTONITE CHIPS, OR BENTONITE SLURRY. DETAILED METHOD OF STATEMENT TO BE SUBMITTED TO DEWA ENGINEER. STEP 5. DEMOLISH EXISTING FOUNDATION AND REMOVE THE UPPER 3 FEET OF THE WELL CASING / CONCRETE CAP WITH SUITABLE REINFORCEMENT. THIS STEP NEVER SHOULD BE DONE BEFORE THE FILL MATERIAL IS WITHIN 3 FEET OF THE SURFACE. UPPER CASING REMOVAL IS PARTICULARLY IMPORTANT IF THE ABANDONED WELL</p>						

## REQUEST FOR QUOTATION LOCAL PURCHASE SECTION

**RFQ NUMBER** : 2332600283  
**DATE** : 30.01.2026  
**REQ No** : 1032600491  
**REQ TITLE** : Plugging 1032600491  
**DELIVERY LOCATION**  
**CLOSING DATE** : 05.02.2026  
**CLOSING TIME** : 10:00:00

SL NO	ITEM CODE	SERVICE ID	DESCRIPTION	QTY	UOM	BRAND/ORIGIN	WARRANTY	UNIT PRICE	TOTAL PRICE
			SITE IS FARMED. REMOVING THE UPPER 3 FEET OF CASING ELIMINATES POTENTIAL DAMAGE TO TILLAGE EQUIPMENT. 0.5 *0.5*0.25 M CONCRETE CAP MANDATORY WITH SUITABLE REINFORCEMENT. ALL THE FOUNDATION TO BE DEMOLISHED AND SCRAP TO DUBAI MUNICIPALITY SCRAP YARD WITH APPROVAL OF DEWA ENGINEER. STEP 6. FILL THE FINAL 3 FEET WITH TOPSOIL AND MOUND. SHAPING THE SITE IS NECESSARY TO PREVENT PONDING OF WATER OVER THE PLUGGED WELL. TOPSOIL SHOULD BE PACKED INTO THE WELL AND MOUNDED UP TO 1½ FEET OVER THE SITE. MOUNDING WILL HELP DIRECT SURFACE WATER AWAY FROM THE SITE AND ALSO WILL HELP ABSORB ANY SETTLING OF FILL MATERIALS.						

TOTAL AMOUNT IN WORDS:

TOTAL AMOUNT:

**SPECIAL NOTES / INSTRUCTIONS:**

Plugging

## REQUEST FOR QUOTATION LOCAL PURCHASE SECTION

<b>RFQ NUMBER</b>	: 2332600283
<b>DATE</b>	: 30.01.2026
<b>REQ No</b>	: 1032600491
<b>REQ TITLE</b>	: Plugging 1032600491
<b>DELIVERY LOCATION</b>	
<b>CLOSING DATE</b>	: 05.02.2026
<b>CLOSING TIME</b>	: 10:00:00

Detailed spec - Plugging / Back filling Existing cancelled wells at  
Different well field and shabias (Al Aweer, Wahoosh, Habab, Margham Well  
Field area <(>&<)> Khawaneej, Murrah, Margham etc..) with Bentonite  
pellets or suitable method. Total 50 Number

Well-plugging steps

Making sure that the proper equipment and materials are on hand will  
make the job much easier, quicker and effective.

Well Details.

Well ID List attached Well Dia : 8" 14" Well Depth: 202 - 300ft SWL

- 130 - 180 ft

Casing Height from EGL : 1 - 2ft

Step 1. Measure the dimensions of the well.

Measurements must be taken of the well diameter, depth and water level.

Accurate measurements (not estimates) will allow the correct calculation  
of the total well volume and the volume of water in the well. This  
information is needed to determine the amount of materials needed for  
plugging. Remember that volume calculations depend on the shape of the  
well. Our wells are cylindrical; however, some have other shapes that  
must be considered for accurate calculation of volume.

## REQUEST FOR QUOTATION LOCAL PURCHASE SECTION

<b>RFQ NUMBER</b>	: 2332600283
<b>DATE</b>	: 30.01.2026
<b>REQ No</b>	: 1032600491
<b>REQ TITLE</b>	: Plugging 1032600491
<b>DELIVERY LOCATION</b>	
<b>CLOSING DATE</b>	: 05.02.2026
<b>CLOSING TIME</b>	: 10:00:00

Step 2. Remove all obstructing materials from the well.

Making sure that fill materials do not slump or settle is critical; therefore, obstructions that may cause incomplete filling of the voids must be removed. Remove the pump, rods, pipes and any other equipment from the well. Floating debris, such as wood staves, also should be removed. One method used to accomplish debris removal is flushing. If water is pumped into the

well, floating debris will move to the top as the well fills with water.

Flushing may not be possible with larger diameter wells due to the volume of water required. In any event, as much debris as possible must be removed from the well before plugging.

Initial well-plugging steps include accurate measurement of the well dimensions and removal of all obstructions.

Step 3. Disinfect the well by adding household bleach.

All wells containing standing water must be disinfected to kill existing microorganisms. This can be accomplished by adding chlorine bleach at the rate of 1 gallon of bleach for every 500 gallons of water and is equivalent to a "shock" chlorination concentration of 100 parts per million of chlorine. The chlorination process ensures that

## REQUEST FOR QUOTATION LOCAL PURCHASE SECTION

<b>RFQ NUMBER</b>	: 2332600283
<b>DATE</b>	: 30.01.2026
<b>REQ No</b>	: 1032600491
<b>REQ TITLE</b>	: Plugging 1032600491
<b>DELIVERY LOCATION</b>	
<b>CLOSING DATE</b>	: 05.02.2026
<b>CLOSING TIME</b>	: 10:00:00

disease-causing microorganisms are not sealed in the aquifer. The chlorination procedure disinfects the well so that disease-causing microorganisms are not sealed in the aquifer after the well is plugged. Step 4. Fill the well with plugging materials. Plugging always begins at the well's bottom. The kind of aquifer, well structure, depth, diameter, material availability, and necessary level of protection will all affect the precise plugging process. The well can be sealed with bentonite, 3/8 gravel, bentonite chips, or bentonite slurry. Detailed Method of statement to be submitted to DEWA Engineer. Step 5. Demolish Existing Foundation and Remove the upper 3 feet of the well casing / Concrete cap with suitable reinforcement. This step never should be done before the fill material is within 3 feet of the surface. Upper casing removal is particularly important if the abandoned well site is farmed. Removing the upper 3 feet of casing eliminates potential damage to tillage equipment/ 0.5 \*0.5\*0.25 m concrete cap mandatory with suitable reinforcement. All the Foundation to be demolished and scrap to Dubai Municipality Scrap yard with approval of DEWA Engineer.

## REQUEST FOR QUOTATION LOCAL PURCHASE SECTION

<b>RFQ NUMBER</b>	: 2332600283
<b>DATE</b>	: 30.01.2026
<b>REQ No</b>	: 1032600491
<b>REQ TITLE</b>	: Plugging 1032600491
<b>DELIVERY LOCATION</b>	
<b>CLOSING DATE</b>	: 05.02.2026
<b>CLOSING TIME</b>	: 10:00:00

Step 6. Fill the final 3 feet with topsoil and mound.

Shaping the site is necessary to prevent ponding of water over the plugged well. Topsoil should be packed into the well and mounded up to 1½ feet over the site. Mounding will help direct surface water away from the site and also will help absorb any settling of fill materials.

### **STANDARD TERMS & CONDITIONS**

- 1) Prices should be 'DDP' delivery duty paid at DEWA stores.
- 2) Quotation to be submitted only in local currency U.A.E Dirhams
- 3) DEWA Standard payment terms is '30 days credit' from the date of acceptance of material
- 4) No DEWA staff or his or her relatives up to third degree should have ownership or partnership in your company, and your participation in DEWA tenders / RFQs should not constitute a Conflict or perceived Conflict of Interest.
- 5) The offered product and/ or services in the Quotation, shall be conforming and in accordance with DEWA Energy Management Policy & EnMS Manual.

## REQUEST FOR QUOTATION LOCAL PURCHASE SECTION

<b>RFQ NUMBER</b>	: 2332600283
<b>DATE</b>	: 30.01.2026
<b>REQ No</b>	: 1032600491
<b>REQ TITLE</b>	: Plugging 1032600491
<b>DELIVERY LOCATION</b>	
<b>CLOSING DATE</b>	: 05.02.2026
<b>CLOSING TIME</b>	: 10:00:00

6) Confidentiality Clause: The Supplier/Service Provider shall treat all information and data (excluding open data) contained in the Purchase Order or obtained by the Supplier/Service Provider in connection with the execution of Works as proprietary and strictly confidential. In particular, the Supplier/Service Provider shall not publish or disclose any data or information including but not limited to personally identifiable information, government data, project details, specifications, drawings or photographs concerning the Works to any third parties without the prior written consent of the Employer.

If the Supplier/Service Provider is obligated to obtain NOCs / Permits /Permissions for the Project from Government agencies as per the terms and scope of the Contract, the Supplier/Service Provider shall submit only the specific data required for the purpose to the authorized team of the agency, through their prescribed channel / system, subject to information security requirements

The Supplier/Service Provider shall comply with all the applicable data protection laws and regulations.

**SUPPLIER'S REMARKS :**

**SUPPLIER'S SIGNATURE AND STAMP**